



## Installation Instructions Quick Step Guide

- 1** Asphalt Art decals can be stuck to most surfaces outdoors including asphalt, textured concrete, pavers etc. Avoid smooth surfaces like tiles as this will be difficult to remove.
- 2** Do not install on wet or even slightly damp surface – it will not stick. If wet the decals can be used next year so don't waste them trying to install on a damp/wet surface
- 3** Sweep the ground thoroughly before installing – little stones will pierce the foil if left underneath
- 4** Peel off rear paper liner. Position on ground then smooth hands across print from centre outwards. If any stones are felt by hands then peel back foil and remove
- 5** Final step it to strike foil with a stiff bristle broom firmly all over the surface. This pushes the foil into the textured surface and ensures more of it sticks to the surface. This is super important and should not be rushed. Don't use a soft bristle broom as this is useless. The only thing that works well is a stiff bristle broom. Check this video for recommended broom action <http://www.visionarydigital.com.au/untitled-ccjb> (scroll to bottom of page)
- 6** Removal is undertaken by simply peeling it off. You might need a Stanley knife to prise up an edge. Once you have an edge to hold onto slowly peel off trying not to tear the foil – lift in one piece if possible.